

SHIFT

PANIC

AUTOCHORD LEARN

EXP/VEL/AT/MOD 0-10V

AUTOCHORD ON

EXP/VEL/AT/MOD 0-5V

AUTOCHORD OFF

GATE RETTRIGGERING = ON/OFF

RESET = CLOCK

(+SHIFT)  
CLOCK/ON OFF

TRANSPPOSE UP

RESET = KEY

TRANSPPOSE DOWN

SPLIT ZONE3

MIDI OUTPUT CHANNEL SELECT

SPLITTING ON/OFF

MIDI INPUT CHANNEL ZONE2

VOICING = 4 VOICE

MIDI INPUT CHANNEL ZONE1

VOICING = 3 VOICE

MIDI INPUT CHANNEL CV/GATE4

MIDI INPUT CHANNEL CV/GATE3

VOICING = 2 VOICE

MIDI INPUT CHANNEL CV/GATE2

VOICING = 1 VOICE

SPLIT ZONE2

MIDI INPUT CHANNEL CV/GATE1

CLOCK DIVISION 6

LFO SHAPE =RANDOM

CLOCK DIVISION 8

LFO SHAPE =SQUARE

CLOCK DIVISION 16

LFO SHAPE =SAWTOOTH

LFO SHAPE =RAMP

MOD WHEEL=LFO

LFO SHAPE =TRIANGLE

MOD WHEEL=MANUAL

SPLIT ZONE1

## Function Keys

GLIDE MODE = LEGATO

ARP SEQUENCER

GLDIE MODE = GLIDE

ARP RANDOM

CV4 - ARP ON/OFF

ARP UP/DOWN

CV3 - ARP ON/OFF

ARP UP/DOWN

CV2 - ARP ON/OFF

ARP DOWN

CV1 - ARP ON/OFF

ARP UP

LOCAL ON/OFF

## NiftyKEYZ